

COLD

HOSE

Fitting Part Number Descriptions

BL 11014-1

Prefix

BL: BeadLock
(Aluminum Tube - Steel Ferrule)
SB: Steel Beadlock
(Steel Tube - Steel Ferrule)
RB: Reduced Beadlock
(Aluminum Tube - Steel Ferrule)
SR: Steel Reduced Beadlock
(Steel Tube - Steel Ferrule)

Not applicable for barb fittings or non-hose ends

Suffix

-1 = 1/4" R12 Service Valve
-2 = 3/16" R12 Service Valve
-3 = R134a Quick Connect
-4 = M10 Switch Port
-5 = M12 Switch Port
-9 = R134a High Side S.V.
SD = Short Drop

Fifth Digit

4 = 14 Hose
Example
SR13034 = 10 FTG X 14 Hose
Where applicable

FIRST TWO DIGITS

11= Female Flare
12= Male Flare
13= Female O-ring
14= Male O-ring
17= Bulkhead Style
18= Male Insert O-ring
19= Adapters
20= Compressor Adapter
Fittings 21= Tube-O & Rotalock
23= Compressor Blocks
41,45= Ford Female Springlock
43= Ford Male Springlock
56= Single Pad Style Comp.
Port 58= Braze/Weld on barb
61= Hose Splicer
62= Auxiliary A/C Tee
63= Splicers
64= R-12 Service Adapter
65= R134a Adapters
66= Braze on Beadlock
83= Metric Adapters
93= Female O-ring Metric
94= Male Insert O-ring Metric
H= Heater Fittings

THIRD DIGIT

0 = Straight
1 = 45 Degree
2 = 90 Degree
Except when 4th digit is a "zero" (rare)

Fourth Digit for English Threads

1 = 6 FTG X 6 Hose
2 = 8 FTG X 8 Hose
3 = 10 FTG X 10 Hose
4 = 12 FTG X 12 Hose
5 = 6 FTG X 8 Hose
6 = 8 FTG X 10 Hose
7 = 10 FTG X 12 Hose
8 = 8 FTG X 6 Hose
9 = 10 FTG X 8 Hose
0 = 12 FTG X 10 Hose

*When 4th digit is a "zero" (rare) then 3rd digit means:

1 = Straight
2 = 45 Degree
3 = 90 Degree

Fourth Digit for Metric Threads

1 = 5 FTG X 6 Hose
2 = M16 FTG X 6 Hose
3 = M18 FTG X 6 Hose
4 = M20 FTG X 6 Hose
5 = M20 FTG X 8 Hose
6 = M22 FTG X 10 Hose
7 = M24 FTG X 10 Hose
8 = M27 FTG X 12 Hose

Customer Support: (800) 223-7167