



Fitting Part Number Descriptions

BL 11014-1

Prefix

BL: BeadLock
(Aluminum Tube - Steel Ferrule)
SB: Steel Beadlock
(Steel Tube - Steel Ferrule)
RB: Reduced Beadlock
(Aluminum Tube - Steel Ferrule)
SR: Steel Reduced Beadlock
(Steel Tube - Steel Ferrule)

Not applicable for barb fittings or non-hose ends

Suffix

-1 = 1/4" R12 Service Valve
 -2 = 3/16" R12 Service Valve
 -3 = R134a Quick Connect
 -4 = M10 Switch Port
 -5 = M12 Switch Port
 -9 = R134a High Side S.V.
 SD =Short Drop

Fifth Digit

4 = 14 Hose
 Example
 SR13034 = 10 FTG X 14 Hose
 Where applicable

FIRST TWO DIGITS

11= Female Flare
 12= Male Flare
 13= Female O-ring
 14= Male O-ring
 17= Bulkhead Style
 18= Male Insert O-ring
 19= Adapters
 20= Compressor Adapter
 Fittings 21= Tube-O & Rotalock
 23= Compressor Blocks
 41,45= Ford Female Springlock
 43= Ford Male Springlock
 56= Single Pad Style Comp.
 Port 58= Braze/Weld on barb
 61= Hose Splicer
 62= Auxiliary A/C Tee
 63= Splicers
 64= R-12 Service Adapter
 65= R134a Adapters
 66= Braze on Beadlock
 83= Metric Adapters
 93= Female O-ring Metric
 94= Male Insert O-ring Metric
 H= Heater Fittings

THIRD DIGIT

0 = Straight
 1 = 45 Degree
 2 = 90 Degree
 Except when 4th digit is a "zero" (rare)

Fourth Digit for English Threads

1 = 6 FTG X 6 Hose
 2 = 8 FTG X 8 Hose
 3 = 10 FTG X 10 Hose
 4 = 12 FTG X 12 Hose
 5 = 6 FTG X 8 Hose
 6 = 8 FTG X 10 Hose
 7 = 10 FTG X 12 Hose
 8 = 8 FTG X 6 Hose
 9 = 10 FTG X 8 Hose
 0 = 12 FTG X 10 Hose

*When 4th digit is a "zero" (rare) then 3rd digit means:

1 = Straight
 2 = 45 Degree
 3 = 90 Degree

Fourth Digit for Metric Threads

1 = 5 FTG X 6 Hose
 2 = M16 FTG X 6 Hose
 3 = M18 FTG X 6 Hose
 4 = M20 FTG X 6 Hose
 5 = M20 FTG X 8 Hose
 6 = M22 FTG X 10 Hose
 7 = M24 FTG X 10 Hose
 8 = M27 FTG X 12 Hose

Customer Support: (800) 223-7167